

# ***DENSO ROBOT***

Vertical articulated

**VS-F SERIES**

**INSTALLATION & MAINTENANCE GUIDE**

Copyright © DENSO WAVE INCORPORATED, 2004

All rights reserved. No part of this publication may be reproduced in any form or by any means without permission in writing from the publisher.

Specifications are subject to change without prior notice.

All products and company names mentioned are trademarks or registered trademarks of their respective holders.

# Preface

Thank you for purchasing this high-speed, high-accuracy assembly robot.

Before operating your robot, read this manual carefully to safely get the maximum benefit from your robot in your assembling operations.

## Robot series and/or models covered by this manual

Series	Model	
	Floor-mount	Overhead-mount
Small-sized, vertical articulated VS-F (Models configured with RC7 controller)	VS-6356F VS-6377F	Same as left.

**NOTE 1:** Model names listed above apply to the models of robot systems. The model names of robot units are followed by M. If the robot system model is VS-6356F, for example, the robot unit model is VS-6356FM.

## Important

To ensure operator safety, be sure to read the precautions and instructions in "SAFETY PRECAUTIONS".

# How the documentation set is organized

The documentation set consists of the following books. If you are unfamiliar with this robot and option(s), please read all books and understand them fully before operating your robot and option(s).

## **GENERAL INFORMATION ABOUT ROBOT**

Provides the packing list of the robot and outlines of the robot system, robot unit, and robot controller.

## **INSTALLATION & MAINTENANCE GUIDE - this book -**

Provides instructions for installing the robot components and customizing your robot, and maintenance & inspection procedures.

## **BEGINNER'S GUIDE**

Introduces you to the DENSO robot. Taking an equipment setup example, this book guides you through running your robot with the teach pendant, making a program in WINCAPSII, and running your robot automatically.

## **SETTING-UP MANUAL**

Describes how to set-up or teach your robot with the teach pendant, operating panel, or mini-pendant.

## **WINCAPSII GUIDE**

Provides instructions on how to use the teaching system WINCAPSII which runs on the PC connected to the robot controller for developing and managing programs.

## **PROGRAMMER'S MANUAL (I), (II)**

Describes the PAC programming language, program development, and command specifications in PAC.

## **RC7 CONTROLLER INTERFACE MANUAL**

Describes the RC7 controller, interfacing with external devices, system- and user-input/output signals, and I/O circuits.

## **ERROR CODE TABLES**

List error codes that will appear on the teach pendant, operating panel, or PC screen if an error occurs in the robot series or WINCAPSII. These tables provide detailed description and recovery ways.

## **OPTIONS MANUAL**

Describes the specifications, installation, and use of optional devices.

# How this book is organized

This book is just one part of the robot documentation set. This book consists of SAFETY PRECAUTIONS, chapters one through three.

## **SAFETY PRECAUTIONS**

Defines safety terms and related symbols and provides precautions that should be observed. Be sure to read this section before operating your robot.

## **Chapter 1 Installing Robot Components**

Provides information about physical site planning, installation procedures, and engineering-design notes for hands.

## **Chapter 2 Customizing Your Robot**

Describes how to customize your robot--defining the software motion space and restricted space, CALSEting, and setting control set of motion optimization.

## **Chapter 3 Maintenance and Inspection**

Describes the regular maintenance and inspections necessary for maintaining the performance and functions of your robot.



# SAFETY PRECAUTIONS

Be sure to observe all of the following safety precautions.

Strict observance of these warning and caution indications are a **MUST** for preventing accidents, which could result in bodily injury and substantial property damage. Make sure you fully understand all definitions of these terms and related symbols given below, before you proceed to the text itself.

 <b>WARNING</b>	Alerts you to those conditions, which could result in serious bodily injury or death if the instructions are not followed correctly.
 <b>CAUTION</b>	Alerts you to those conditions, which could result in minor bodily injury or substantial property damage if the instructions are not followed correctly.

## Terminology and Definitions

**Maximum space:** Refers to the volume of space encompassing the maximum designed movements of all robot parts including the end-effector, workpiece and attachments. (Quoted from the RIA\* Committee Draft.)

**Restricted space:** Refers to the portion of the maximum space to which a robot is restricted by limiting devices (i.e., mechanical stops). The maximum distance that the robot, end-effector, and workpiece can travel after the limiting device is actuated defines the boundaries of the restricted space of the robot. (Quoted from the RIA Committee Draft.)

**Motion space:** Refers to the portion of the restricted space to which a robot is restricted by software motion limits. The maximum distance that the robot, end-effector, and workpiece can travel after the software motion limits are set defines the boundaries of the motion space of the robot. (The "motion space" is DENSO WAVE-proprietary terminology.)

**Operating space:** Refers to the portion of the restricted space (or motion space in Denso robot) that is actually used by the robot while performing its task program. (Quoted from the RIA Committee Draft.)

**Task program:** Refers to a set of instructions for motion and auxiliary functions that define the specific intended task of the robot system. (Quoted from the RIA Committee Draft.)

(\*RIA: Robotic Industries Association)

---

## 1. Introduction

This section provides safety precautions to be observed during installation, teaching, inspection, adjustment, and maintenance of the robot.

## 2. Installation Precautions

### 2.1 Insuring the proper installation environment

#### 2.1.1 For standard type

The standard type has not been designed to withstand explosions, dust-proof, nor is it splash-proof. Therefore, it should not be installed in any environment where:

- (1) there are flammable gases or liquids,
- (2) there are any shavings from metal processing or other conductive material flying about,
- (3) there are any acidic, alkaline or other corrosive gases,
- (4) there is cutting or grinding oil mist,
- (5) it may likely be submerged in fluid,
- (6) there is sulfuric cutting or grinding oil mist, or
- (7) there are any large-sized inverters, high output/high frequency transmitters, large contactors, welders, or other sources of electrical noise.

#### 2.1.2 For dust-proof, splash-proof type

The dust-proof, splash-proof type is an IP54-equivalent structure, but it has not been designed to withstand explosions. (The HM/HS-E-W and the wrist of the VM-D-W/VS-E-W are an IP65-equivalent dust-proof and splash-proof structure.)

Note that the robot controller is not a dust- or splash-proof structure. Therefore, when using the robot controller in an environment exposed to mist, put it in an optional protective box.

The dust-proof, splash-proof type should not be installed in any environment where:

- (1) there are any flammable gases or liquids,
- (2) there are any acidic, alkaline or other corrosive gases,
- (3) there are any large-sized inverters, high output/high frequency transmitters, large contactors, welders, or other sources of electrical noise,
- (4) it may likely be submerged in fluid,
- (5) there are any grinding or machining chips or shavings,
- (6) any machining oil not specified in this manual is in use, or  
Note: Yushiron Oil No. 4C (non-soluble) is specified.
- (7) there is sulfuric cutting or grinding oil mist.

### 2.2 Service space


The robot and peripheral equipment should be installed so that sufficient service space is maintained for safe teaching, maintenance, and inspection.

## SAFETY PRECAUTIONS

---

- 2.3 Control devices outside the robot's restricted space** The robot controller, teach pendant, and operating panel should be installed outside the robot's restricted space and in a place where you can observe all of the robot's movements when operating the robot controller, teach pendant, or operating panel.
- 2.4 Positioning of gauges** Pressure gauges, oil pressure gauges and other gauges should be installed in an easy-to-check location.
- 2.5 Protection of electrical wiring and hydraulic/pneumatic piping** If there is any possibility of the electrical wiring or hydraulic/pneumatic piping being damaged, protect them with a cover or similar item.
- 2.6 Positioning of emergency stop switches** Emergency stop switches should be provided in a position where they can be reached easily should it be necessary to stop the robot immediately.
- (1) The emergency stop switches should be red.
  - (2) Emergency stop switches should be designed so that they will not be released after pressed, automatically or mistakenly by any other person.
  - (3) Emergency stop switches should be separate from the power switch.
- 2.7 Positioning of operating status indicators** Operating status indicators should be positioned in such a way where workers can easily see whether the robot is on temporary halt or on an emergency or abnormal stop.

## 2.8 Setting-up the safety fence or enclosure



A safety fence or enclosure should be set up so that no one can easily enter the robot's restricted space. If it is impossible, utilize other protectors as described in Section 2.9.

- (1) The fence or enclosure should be constructed so that it cannot be easily moved or removed.
- (2) The fence or enclosure should be constructed so that it cannot be easily damaged or deformed through external force.
- (3) Establish the exit/entrance to the fence or enclosure. Construct the fence or enclosure so that no one can easily get past it by climbing over the fence or enclosure.
- (4) The fence or enclosure should be constructed to ensure that it is not possible for hands or any other parts of the body to get through it.
- (5) Take any one of the following protections for the entrance/exit of the fence or enclosure:
  - 1) Place a door, rope or chain across the entrance/exit of the fence or enclosure, and fit it with an interlock that ensures the emergency stop device operates automatically if it is opened or removed.
  - 2) Post a warning notice at the entrance/exit of the fence or enclosure stating "In operation--Entry forbidden" or "Work in progress--Do not operate" and ensure that workers follow these instructions at all times.

When making a test run, before setting up the fence or enclosure, place an overseer in a position outside the robot's restricted space and one in which he/she can see all of the robot's movements. The overseer should prevent workers from entering the robot's restricted space and be devoted solely to that task.

## 2.9 Positioning of rope or chain

If it is not possible to set up the safety fence or enclosure described in Section 2.8, hang a rope or chain around the perimeter of the robot's restricted space to ensure that no one can enter the restricted space.

- (1) Ensure the support posts cannot be moved easily.
- (2) Ensure that the rope or chain's color or material can easily be discerned from the surrounds.
- (3) Post a warning notice in a position where it is easy to see stating "In operation--Entry forbidden" or "Work in progress --Do not operate" and ensure that workers follow these instructions at all times.
- (4) Set the exit/entrance, and follow the instructions given in Section 2.8, (3) through (5).

## SAFETY PRECAUTIONS

### 2.10 Setting the robot's motion space

The area required for the robot to work is called the robot's operating space.

If the robot's motion space is greater than the operating space, it is recommended that you set a smaller motion space to prevent the robot from interfering or disrupting other equipment.

Refer to the "INSTALLATION & MAINTENANCE GUIDE."

### 2.11 No robot modification allowed

Never modify the robot unit, robot controller, teach pendant or other devices.

### 2.12 Cleaning of tools

If your robot uses welding guns, paint spray nozzles, or other end-effectors requiring cleaning, it is recommended that the cleaning process be carried out automatically.

### 2.13 Lighting



Sufficient illumination should be assured for safe robot operation.

### 2.14 Protection from objects thrown by the end-effector

If there is any risk of workers being injured in the event that the object being held by the end-effector is dropped or thrown by the end-effector, consider the size, weight, temperature and chemical nature of the object and take appropriate safeguards to ensure safety.

### 2.15 Affixing the warning label

Place the warning label packaged with the robot on the exit/entrance of the safety fence or in a position where it is easy to see.



### 3. Precautions while robot is running



**Warning**

Touching the robot while it is in operation can lead to serious injury. Please ensure the following conditions are maintained and that the cautions listed from Section 3.1 onwards are followed when any work is being performed.



- 1) Do not enter the robot's restricted space when the robot is in operation or when the motor power is on.
- 2) As a precaution against malfunction, ensure that an emergency stop device is activated to cut the power to the robot motor upon entry into the robot's restricted space.
- 3) When it is necessary to enter the robot's restricted space to perform teaching or maintenance work while the robot is running, ensure that the steps described in Section 3.3 "Ensuring safety of workers performing jobs within the robot's restricted space" are taken.

#### 3.1 Creation of working regulations and assuring worker adherence

When entering the robot's restricted space to perform teaching or maintenance inspections, set "working regulations" for the following items and ensure workers adhere to them.

- (1) Operating procedures required to run the robot.
- (2) Robot speed when performing teaching.
- (3) Signaling methods to be used when more than one worker is to perform work.
- (4) Steps that must be taken by the worker in the event of a malfunction, according to the contents of the malfunction.
- (5) The necessary steps for checking release and safety of the malfunction status, in order to restart the robot after robot movement has been stopped due to activation of the emergency stop device
- (6) Apart from the above, any steps below necessary to prevent danger from unexpected robot movement or malfunction of the robot.
  - 1) Display of the control panel (See Section 3.2 on the following page)
  - 2) Assuring the safety of workers performing jobs within the robot's restricted space (See Section 3.3 on the following page)

3) Maintaining worker position and stance

Position and stance that enables the worker to confirm normal robot operation and to take immediate refuge if a malfunction occurs.

4) Implementation of measures for noise prevention

5) Signaling methods for workers of related equipment

6) Types of malfunctions and how to distinguish them

Please ensure "working regulations" are appropriate to the robot type, the place of installation and to the content of the work.

Be sure to consult the opinions of related workers, engineers at the equipment manufacturer and that of a labor safety consultant when creating these "working regulations".

### **3.2 Display of operation panel**

To prevent anyone other than the worker from accessing the start switch or the changeover switch by accident during operation, display something to indicate it is in operation on the operating panel or teach pendant. Take any other steps as appropriate, such as locking the cover.

### **3.3 Ensuring safety of workers performing jobs within the robot's restricted space**

When performing jobs within the robot's restricted space, take any of the following steps to ensure that robot operation can be stopped immediately upon a malfunction.

- (1) Ensure an overseer is placed in a position outside the robot's restricted space and one in which he/she can see all robot movements, and that he/she is devoted solely to that task.
  - ① An emergency stop device should be activated immediately upon a malfunction.
  - ② Do not permit anyone other than the worker engaged for that job to enter the robot's restricted space.
- (2) Ensure a worker within the robot's restricted space carries the portable emergency stop switch so he/she can press it (the robot stop button on the teach pendant) immediately if it should be necessary to do so.

---

### **3.4 Inspections before commencing work such as teaching**

Before starting work such as teaching, inspect the following items, carry out any repairs immediately upon detection of a malfunction and perform any other necessary measures.

- (1) Check for any damage to the sheath or cover of the external wiring or to the external devices.
- (2) Check that the robot is functioning normally or not (any unusual noise or vibration during operation).
- (3) Check the functioning of the emergency stop device.
- (4) Check there is no leakage of air or oil from any pipes.
- (5) Check there are no obstructive objects in or near the robot's restricted space.

### **3.5 Release of residual air pressure**

Before disassembling or replacing pneumatic parts, first release any residual air pressure in the drive cylinder.

### **3.6 Precautions for test runs**

Whenever possible, have the worker stay outside of the robot's restricted space when performing test runs.

### **3.7 Precautions for automatic operation**

#### (1) At start-up

Before the robot is to be started up, first check the following items as well as setting the signals to be used and perform signaling practice with all related workers.

- 1) Check that there is no one inside the robot's restricted space.
- 2) Check that the teach pendant and tools are in their designated places.
- 3) Check that no lamps indicating a malfunction on the robot or related equipment are lit.

#### (2) Check that the display lamp indicating automatic operation is lit during automatic operation.

#### (3) Steps to be taken when a malfunction occurs

Should a malfunction occur with the robot or related equipment and it is necessary to enter the robot's restricted space to perform emergency maintenance, stop the robot's operation by activating the emergency stop device. Take any necessary steps such as placing a display on the starter switch to indicate work is in progress to prevent anyone from accessing the robot.

### 3.8 Precautions in repairs

- (1) Do not perform repairs outside of the designated range.
- (2) Under no circumstances should the interlock mechanism be removed.
- (3) When opening the robot controller's cover for battery replacement or any other reasons, always turn the robot controller power off and disconnect the power cable.
- (4) Use only spare tools specified in this manual.

### 4. Daily and periodical inspections

- (1) Be sure to perform daily and periodical inspections. Before starting jobs, always check that there is no problem with the robot and related equipment. If any problems are found, take any necessary measures to correct them.
- (2) When carrying out periodical inspections or any repairs, maintain records and keep them for at least 3 years.

### 5. Management of floppy disks

- (1) Carefully handle and store the "Initial settings" floppy disks packaged with the robot, which store special data exclusively prepared for your robot.
- (2) After finishing teaching or making any changes, always save the programs and data onto floppy disks.  

Making back-ups will help you recover if data stored in the robot controller is lost due to the expired life of the back-up battery.
- (3) Write the names of each of the floppy disks used for storing task programs to prevent incorrect disks from loading into the robot controller.
- (4) Store the floppy disks where they will not be exposed to dust, humidity and magnetic field, which could corrupt the disks or data stored on them.



# Contents

<b>Preface</b> .....	<b>i</b>
<b>How the documentation set is organized</b> .....	<b>ii</b>
<b>How this book is organized</b> .....	<b>iii</b>
<b>SAFETY PRECAUTIONS</b>	
<b>Chapter 1 Installing Robot Components</b> .....	<b>1</b>
1.1 Preparing a Proper Environment for Installation.....	1
1.1.1 Installation Environments.....	1
1.1.2 Ambient Temperature and Humidity .....	2
1.1.3 Vibration.....	2
1.1.4 Connecting the Robot Unit and Robot Controller .....	2
1.1.5 Installation Environment of the Robot Unit .....	2
1.2 Installing the Robot Unit.....	5
1.2.1 Caution at floor-mount installation of the dust-proof & splash-proof type robot unit.....	5
1.2.2 Transporting the Robot Unit.....	6
1.2.3 Installing the Robot Unit .....	9
1.2.4 Grounding the Robot Unit .....	10
1.3 Installing the Robot Controller.....	10
1.4 Cautions for Designing the Robot Hand .....	11
<b>Chapter 2 Customizing Your Robot</b> .....	<b>14</b>
2.1 What Is Customization? .....	14
2.2 Modifying Software Motion Limits to Define New Motion Space.....	15
2.2.1 What Is a Software Motion Limit? .....	15
2.2.2 Factory Defaults of Software Motion Limits.....	16
2.2.3 Changing Software Motion Limits .....	17
2.2.4 Precautions When Changing the Software Motion Limits .....	18
2.2.5 Procedure for Changing the Software Motion Limits .....	18
2.3 Changing the Mechanical End .....	21
2.4 CALSET.....	51
2.4.1 What Is CALSET?.....	51
2.4.2 Precautions about CALSET for the VS-F Series.....	51
2.4.3 Preparation for CALSET.....	53
2.4.4 Mounting the CALSET Jig.....	55
2.4.5 What Is a CALSET Position?.....	59
2.4.6 CALSET Procedure.....	60
2.5 Setting Control Set of Motion Optimization .....	66
2.6 Setting Robot Installation Conditions .....	67

<b>Chapter 3 Maintenance and Inspection</b> .....	<b>68</b>
3.1 Maintenance & Inspection Intervals and Purposes .....	68
3.2 Daily Inspections.....	69
3.2.1 Check Items.....	69
3.3 Quarterly Inspections .....	70
3.3.1 Check Items.....	70
3.3.2 Cleaning the Air Intake Filter in the Robot Controller .....	70
3.4 Biennial Inspections .....	71
3.4.1 Battery Replacement and Check Items.....	71
3.4.2 Replacing the Encoder Backup Battery.....	72
3.4.3 Replacing the Memory Backup Battery .....	76
3.4.4 Setting the Next Battery Replacement Date .....	76
3.5 Supplies and Tools for Maintenance .....	77
3.5.1 Supplies and Tools Required .....	77
3.5.2 Recommended Tools .....	77
3.6 Replacing Fuses and Output ICs .....	77
3.7 Checking the Odometer and Trip Meter.....	78
3.7.1 Displaying the Odometer, Trip Meter, and Oil Change Intervals .....	78
3.7.2 Resetting the Trip Meter to Zero .....	80
3.8 Checking the Controller ON-Time and the Robot Running Time and Resetting Their User Counters.....	82
3.8.1 Displaying the Controller ON-time and the Robot Running Time .....	82
3.8.2 Resetting the User Counters of the Controller ON-Time and the Robot Running Time .....	84
3.9 Resetting Encoders.....	87
3.10 Using the Initialization Floppy Disk .....	88

**Index**

# Chapter 1 Installing Robot Components

## 1.1 Preparing a Proper Environment for Installation

Before installing the robot unit and robot controller, confirm that the operating environment is in conformity with each item of "SAFETY PRECAUTIONS, 2. Installation Precautions," and that the surrounding environment of the location where the robot is to be used meets the specifications as described below. Also, take proper measures to protect the components from vibration.

In an inappropriate environment, the robot will not operate to its full capacity or performance, components may not last long, and unexpected failure may result.

### 1.1.1 Installation Environments

#### ■ Standard Type

The robot is not explosion-proof, dust-proof or splash-proof, so it should not be installed in any environment where:

- (1) there are flammable gases or liquids,
- (2) there are any shavings from metal processing or other conductive material flying about,
- (3) there are any acidic, alkaline or other corrosive gases,
- (4) there is cutting or grinding oil mist,
- (5) there is sulfuric cutting or grinding oil mist, or
- (6) there are any large-sized inverters, high output/high frequency transmitters, large contactors, welders, or other sources of electrical noise.

#### ■ Dust-proof, Splash-proof Type

The robot is IP54-equivalent dust-proof and splash-proof, but it is not designed to withstand explosions. (The wrist is an IP65-equivalent dust-proof and splash-proof structure.)

Note that the robot controller is not a dust- or splash-proof structure. Therefore, when using the robot controller in an environment exposed to mist, put it in an optional protective box.

The dust-proof, splash-proof type should not be installed in any environment where:

- (1) there are flammable gases or liquids,
- (2) there are any acidic, alkaline or other corrosive gases,
- (3) there are any large-sized inverters, high output/high frequency transmitters, large contactors, welders, or other sources of electrical noise,
- (4) it may likely be submerged in fluid,
- (5) there are any grinding or machining chips or shavings,
- (6) any machining oil not specified in this manual is in use, or  
**NOTE:** Yushiron Oil No. 4C (non-soluble) is specified.
- (7) there is sulfuric cutting or grinding oil mist.

## 1.1.2 Ambient Temperature and Humidity

Keep the ambient temperature between 0°C and 40°C during operation.

Keep the ambient humidity at 90% or below to prevent dew condensation.

## 1.1.3 Vibration

Do not install the robot in an environment where it will be exposed to excessive vibration or impact.

**Caution:** When the excessive vibration is added to the robot unit at power-off during transportation, ERROR 2AF1 (Encoder reference position error) may occur. If the ERROR 2AF1 occurs when turning the robot controller ON at first after purchasing the robot, refer to the "ERROR CODE TABLES" or contact our Robot Service Section.

## 1.1.4 Connecting the Robot Unit and Robot Controller

Before delivery, the robot unit and the robot controller are configured as a set. If you purchase two or more robot systems, take care not to mistake each set when connecting robot units and controllers.

 **Caution** For the position of the serial number, see "1.3 [2] Outer Dimensions and Operating Range" for the robot unit and "1.4 [2] Outer Dimensions" for the robot controller.


## 1.1.5 Installation Environment of the Robot Unit

The installation requirements for the robot unit are shown on the next page. Prepare a highly rigid mount by referring to the figure on page 4.

 **Caution** Do not electric-weld the equipment including the robot. A large current may flow through the motor encoder or robot controller resulting in a failure. If electric welding is required, remove the robot unit and the robot controller from the equipment beforehand.

### Installation Requirements for the Robot Unit


Item	Environments and Conditions	
Flatness of the mount	0.1/500 mm (See the upper figure on the next page.)	
Rigidity of the mount	Use steel materials. (See the figure on the next page.)	
Installation type	Floor-mount or Overhead-mount	
Ambient temperature	During operation : 0 to 40°C During storage and transportation : -10 to 60°C	
Humidity	During operation : 90% or less (No dew condensation allowed.) During storage and transportation : 75% or less (No dew condensation allowed.)	
Vibration	During operation : 4.9 m/s <sup>2</sup> (0.5G) or less During storage and transportation : 29.4 m/s <sup>2</sup> (3G) or less	
Safe installation environment	The robot should not be installed in an environment where: <ul style="list-style-type: none"> <li>• there are flammable gases or liquids,</li> <li>• there are any acidic, alkaline or other corrosive gases,</li> <li>• there is sulfuric cutting or grinding oil mist, or</li> <li>• there are any large-sized inverters, high output/high frequency transmitters, large contactors, welders, or other sources of electrical noise.</li> </ul>	
	Standard type (IP40 – equivalent dust-proof and splash-proof structure)	The robot should not be installed in an environment where: <ul style="list-style-type: none"> <li>• there are any shavings from metal processing or other conductive material flying about,</li> <li>• there is cutting or grinding oil mist, or</li> <li>• it may be directly exposed to water, oil or cutting chips.</li> </ul>
	Dust-proof, splash-proof type (IP54-equivalent dust-proof and splash-proof structure. The wrist is IP65-equivalent.)	The robot should not be installed in an environment where: <ul style="list-style-type: none"> <li>• it may likely be submerged in fluid,</li> <li>• there are any grinding or machining chips or shavings, or</li> <li>• any machining oil other than DENSO authorized Yushiron Oil No. 4C (non-soluble) is in use.</li> </ul>
Working space, etc.	<ul style="list-style-type: none"> <li>• Sufficient service space must be available for inspection and disassembly.</li> <li>• Keep wiring space (230 mm or more) behind the robot, and fasten the wiring to the mounting face or beam so that the weight of the cables will not be directly applied to the connectors.</li> </ul>	
Installation conditions	Grounding resistance: 100 Ω or less See the figure on page 9.	



**⚠ Caution (1)** When the robot operates at high speed, the robot mount undergoes large reaction forces. The mount must be rigid enough so that it will not vibrate or be displaced due to reaction forces. It is also advisable to mechanically join the robot mount with heavy equipment.

(2) Some mounts may produce a resonance sound (howling). If this sound is loud, increase the rigidity of the mount or slightly modify the robot speed.

**Robot Mount Example for Floor-mount**



**⚠ Caution (1)** When the robot operates at high speed, the top plate structure undergoes large reaction forces. Design the vibration-proof mount so that the top plate will not vibrate due to reaction forces. Also design the top plate structure so that it separates from other top plate structures in the equipment.

(2) Some mounts may produce a resonance sound (howling). If this sound is loud, increase the rigidity of the mount or slightly modify the robot speed.

**Robot Mount Example for Overhead-mount**

## 1.2 Installing the Robot Unit


**⚠ Caution** Before handling or installing the robot unit, be sure to read "SAFETY PRECAUTIONS, 2. Installation Precautions."

### 1.2.1 Caution at floor-mount installation of the dust-proof & splash-proof type robot unit

For the dust-proof & splash-proof type robot unit, the drain-bolt (M3 x 8mm) is screwed onto the rear side of the robot unit as shown in the figure below.

At the floor-mount installation, remove the drain-bolt shown in the figure below, before installing the robot unit. It will become a drain-hole for the liquid.

**⚠ Caution:** At the overhead-mount installation, do not remove the drain-bolt when installing the robot unit. If you do so, the robot failure may occur.



Drain bolt of the dust-proof & splash-proof type robot unit

## 1.2.2 Transporting the Robot Unit

### (1) Precautions in transporting the robot


The VS-F series weighs approximately 30 kg. Use a crane suitable for the robot weight.

Have at least two workers handle this job.

Workers should wear helmets, safety shoes, and gloves during transport.



**⚠ Caution** Pass the hoisting wires through the specified eyebolts as illustrated below. Passing them through other sections may drop the robot unit, resulting in a broken robot or bodily injuries.


Do not hold the first arm, elbow, either side of the 2nd arm, 2nd-axis cover, or 3rd-axis cover, or apply force to any of them.



Hoisting Points for Transportation (VS-F series)

**(2) Transporting the robot unit**

No.	Procedure	Explanatory Illustration												
1	<p>Before transportation, set the robot in a transport position as shown at right by manually moving the second, third and fourth axes.</p> <p>When unpacked first, the robot is in the transport position, so this job is not required.</p>	<div style="text-align: center;">  <p><b>Transport Position</b></p> <table border="1" data-bbox="616 808 1466 1014"> <thead> <tr> <th>Axis</th> <th>Angle</th> </tr> </thead> <tbody> <tr> <td>First axis (J1)</td> <td>0°</td> </tr> <tr> <td>Second axis (J2)</td> <td>-55°</td> </tr> <tr> <td>Third axis (J3)</td> <td>+163°</td> </tr> <tr> <td>Fourth axis (J4)</td> <td>-90°</td> </tr> <tr> <td>Fifth axis (J5)</td> <td>-90°</td> </tr> </tbody> </table> </div>	Axis	Angle	First axis (J1)	0°	Second axis (J2)	-55°	Third axis (J3)	+163°	Fourth axis (J4)	-90°	Fifth axis (J5)	-90°
Axis	Angle													
First axis (J1)	0°													
Second axis (J2)	-55°													
Third axis (J3)	+163°													
Fourth axis (J4)	-90°													
Fifth axis (J5)	-90°													
2	<p>Disconnect the robot control cable, air piping and user signal cables from the robot unit.</p> <p>When the robot unit is first unpacked, this job is not required.</p>													
3	<p>As shown at right, mount the eyebolts.</p> <p>When delivered, the robot unit is packed with eyebolts attached, so this job is not required.</p>	<div style="text-align: center;">  <p><b>Mounting Eyebolts</b></p> </div>												

No.	Procedure	Explanatory Illustration
4	As shown at right, place a waste cloth on the second arm and pass the wire through the two eyebolts.	 <p style="text-align: center;"><b>Hoisting the Robot Unit</b></p>
5	Worker A: Remove the four bolts while supporting the robot unit to prevent it from getting overturned.	
6	Worker B: Operate the crane and move the robot unit to the target site.	
7	Worker B: Put the robot unit down in the target position. Worker A: Temporarily secure the robot unit with four bolts.	
8	Secure the robot unit according to the instructions in "[ 2 ] Installing the Robot Unit" on the next page.	
9	Remove the eyebolts from the robot unit.	


**⚠ Caution** (1) Before transporting the robot, check that the path to the target position is free of obstacles.  
(2) Before running the robot unit, be sure to remove the eyebolts. Otherwise, the robot arm will strike against those eyebolts.



## 1.2.4 Grounding the Robot Unit

Ground the grounding terminal of the robot unit with a wire of 5.5 mm<sup>2</sup> or more.

**NOTE:** Use a dedicated grounding wire and grounding electrode. Do not share them with any other electric power or power equipment such as a welder.



Grounding the Robot Unit (VS-F series)

## 1.3 Installing the Robot Controller

For the installing procedures of the robot controller, refer to the “Section 6.2 Installing the Robot Controller, RC7 CONTROLLER INTERFACE MANUAL”.

## 1.4 Cautions for Designing the Robot Hand

Design an end-effector such that it is in compliance with items (1) to (3) described below.



### CAUTION

If the end-effector design precautions are not observed, the clamped parts of the robot unit may become loose, rattle or be out of position. In the worst case, the mechanical parts of the robot and robot controller may become damaged.


#### (1) Mass of end-effector

Design the end-effector so that the total mass of the end-effector (including workpiece) will be lighter than the maximum payload capacity of the robot. The total mass includes the wiring, piping, etc.

**Max. total mass of end-effector (inc. workpiece)  $\leq$  Max. payload capacity (3 kg)**

#### (2) Center of gravity position of end-effector

Design an end-effector so that the center of gravity position of the end-effector (including workpiece) is within the range shown in the figure below.



**Allowable Range of Center of Gravity Position of End-effector (VS-F series)**

**(3) Moment of inertia around J4, J5 and J6**






Design an end-effector so that its moments of inertia around J4, J5 and J6 (including workpiece) do not exceed the maximum allowable moment of inertia of the robot.

**Moment of inertia around J4, J5 and J6 of end-effector (incl. mass of workpiece) ≤ Max. allowable moment of inertia**

- ① Max. allowable moment of inertia around J4 and J5: **0.295 kgm<sup>2</sup>**
- ② Max. allowable moment of inertia around J6: **0.045 kgm<sup>2</sup>**

When calculating the moments of inertia around J4, J5 and J6 of the end-effector, use the formulas shown in the table below and the figure on the next page.


**Moment-of-Inertia Formulas (VS-E series)**

<p>1. Cylinder (1) (Axis of rotation = Center axis)</p>  $I = \frac{mr^2}{2}$	<p>4. Sphere (Axis of rotation = Center axis)</p>  $I = \frac{2mr^2}{5}$
<p>2. Cylinder (2) (The axis of rotation passes through the center of gravity.)</p>  $I = \frac{m}{4} \left( r^2 + \frac{l^2}{3} \right)$	<p>5. Center of gravity not on the axis of rotation</p>  <p><math>I_g</math>: Inertia moment around center of gravity [kgm<sup>2</sup>]</p> $I = I_g + m\ell^2$
<p>3. Rectangular parallelepiped (The axis of rotation passes through the center of gravity.)</p>  $I = \frac{m}{12} (b^2 + c^2)$	<p><math>I</math>: Moment of inertia (kgm<sup>2</sup>)</p> <p><math>m</math>: Mass (kg)</p> <p><math>r</math>: Radius (m)</p> <p><math>b, c, \ell</math>: Length (m)</p>

Calculation example : When calculating the moment of inertia of a complicated shape, divide it into simple parts as much as possible for easier calculations.

As shown in the figure below, divide the end-effector into three parts (①, ②, ③).

(1) Moment of inertia around J6



Moment of inertia around J6 of ①:  $I_1$  (from 3 and 5 in the table on the preceding page)

$$I_1 = \frac{0.14}{12} (0.12^2 + 0.015^2) + 0.14 \times 0.01^2 = 1.85 \times 10^{-4} \text{ [kgm}^2\text{]}$$

Moment of inertia around J6 of ②:  $I_2$  (from 1 and 5 in the table on the preceding page)

$$I_2 = \frac{0.1 \times 0.01^2}{2} + 0.1 \times 0.04^2 = 1.65 \times 10^{-4} \text{ [kgm}^2\text{]}$$

Moment of inertia around J6 of ③:  $I_3$  (from 1 and 5 in the table on the preceding page)


$$I_3 = \frac{1.0 \times 0.02^2}{2} + 1.0 \times 0.05^2 = 2.7 \times 10^{-3} \text{ [kgm}^2\text{]}$$

Moment of inertia around J6 of entire end-effector:  $I_{J6}$

$$I_{J6} = I_1 + I_2 + I_3 = 0.003 \text{ [kgm}^2\text{]}$$

(2) Moment of inertia around J4 and J5

For the end-effector shown below, the moment of inertia around J4 and J5 can be calculated according to the same formula.



Moment of inertia around J4 and J5 of ①:  $I_1$  (from 3 and 5 in the table on the preceding page)

$$I_1 = \frac{0.14}{12} (0.015^2 + 0.01^2) + 0.14 \times ((0.08 + 0.005)^2 + 0.01) = 1.03 \times 10^{-3} \text{ [kgm}^2\text{]}$$

Moment of inertia around J4 and J5 of ②:  $I_2$  (from 2 and 5 in the table on the preceding page)

$$I_2 = \frac{0.1}{4} \left( 0.01^2 + \frac{0.04^2}{3} \right) + 0.1 \times ((0.08 + 0.01 + 0.02)^2 + 0.04^2) = 1.39 \times 10^{-3} \text{ [kgm}^2\text{]}$$

Moment of inertia around J4 and J5 of ③:  $I_3$  (from 2 and 5 in the table on the preceding page)

$$I_3 = \frac{1.0}{4} \left( 0.02^2 + \frac{0.1^2}{3} \right) + 1.0 \times ((0.08 + 0.01 + 0.05)^2 + 0.05^2) = 2.30 \times 10^{-3} \text{ [kgm}^2\text{]}$$

Moment of inertia around J4 and J5 of entire end-effector:  $I_{J4}, I_{J5}$

$$I_{J4} = I_{J5} = I_1 + I_2 + I_3 = 2.54 \times 10^{-2} \text{ [kgm}^2\text{]}$$

End-effector Moment of Inertia Calculation Example (VS-F series)

# Chapter 2 Customizing Your Robot

## 2.1 What Is Customization?

You may customize your robot by modifying or setting the following:

- Software motion limits for defining motion space
- Mechanical ends for defining restricted space
- Control set of motion optimization
- Robot installation conditions

You are recommended to define new motion space and restricted space in order to prevent interference with other devices or entanglement of the end-effector wiring and piping.

### **WARNING:**

Always set the software motion limits and mechanical ends so that the motion space will be within the restricted space. Otherwise, the robot will bump the mechanical stops, causing serious accidents.

## 2.2 Modifying Software Motion Limits to Define New Motion Space


### 2.2.1 What Is a Software Motion Limit?

A limit to the operation range of the robot defined by the software is called a software motion limit. Software motion limits become valid after CAL of the robot has been completed and the robot has entered the range set by the limits.

A mechanical operation limit is called a mechanical end and set by a mechanical stop. To prevent the robot from striking against a mechanical stop, each software motion limit is set slightly in front of the mechanical end as shown in the figure below. Although there is no mechanical stop for the 6th axis, a software motion limit is set.

If the robot reaches a software motion limit during manual or automatic operation, an error message will be displayed (error code starting from 6070; the first digit represents the axis number) and the robot will come to a stop. The power to the motor is also turned OFF in such a case during automatic operation.

All axes are assigned a software motion limit in both the positive and negative direction of the operation range. The software motion limit in the positive direction is called the positive-direction software motion limit and that in the negative direction is called the negative-direction software motion limit.



**Software Motion Limits and Mechanical Ends**

## 2.2.2 Factory Defaults of Software Motion Limits

The table below lists the software motion limits that are set at the time of delivery.

**Factory Defaults of Software Motion Limits (VS-F series)**

Robot model		1st axis	2nd axis	3rd axis	4th axis	5th axis	6th axis
VS-6556E (See NOTE.)	Positive direction	170°	135°	166°	190°	120°	360°
	Negative direction	-170°	-100° max.	-119° max.	-190°	-120°	-360°
VS-6577E	Positive direction	170°	135°	169°	190°	120°	360°
	Negative direction	-170°	-100°	-119°	-190°	-120°	-360°


NOTE: The 2nd and 3rd axes of the VS-6356F are restricted in workable spaces according to the robot posture.

## 2.2.3 Changing Software Motion Limits


If the robot interferes with any other device, change the software motion limits to make the motion space smaller as shown in the upper figure on this page.

If the air piping or wiring of the end-effector becomes taut as the robot runs, then change the software motion limits to make the motion space smaller as shown in the lower figure on this page.

**NOTE:** When changing software motion limits, always make the new motion space smaller than the motion space defined by initial settings.



**Example 1: Changing Software Motion Limits [VS-F series]**



**Example 2: Changing Software Motion Limits [VS-F series]**

## 2.2.4 Precautions When Changing the Software Motion Limits

- (1) The software motion limits are invalid until CAL is completed.
- (2) Confirm the operating space of the robot in the actual working environment. Set the software motion limits using the correct unit of measurement.

If the operating space is too small, the robot may seem to become inoperable.

## 2.2.5 Procedure for Changing the Software Motion Limits

Described below is the procedure for changing the software motion limits.

### ▶ STEP 1


Turn the power switch of the robot controller to ON.

### ▶ STEP 2

Set the mode selector switch of the teach pendant to MANUAL.

### ▶ STEP 3

Press [F2 Arm] on the top screen of the teach pendant.




F2

The Current Robot Position window appears as shown in Step 4.

## ▶ STEP 4

Press the SHIFT key and then press [F12 Maint.].




F12

The Maintenance Functions (Arm) window will appear.

## ▶ STEP 5

Press [F1 M Space] on the Maintenance Functions (Arm) window.

The Motion Space window will appear as shown below.




F5

## ▶ STEP 6

Select the item to be modified, then press [F5 Change].

The numeric keypad will appear as shown below.



Enter a desired value using the numeric keys, then press OK.

The new value will be set on the line of the item selected in the Motion Space window.

If two or more items must be changed, repeat Steps 4 and 5.

## ▶ STEP 7

Press OK in the Motion Space (Software motion limit) window.

## ▶ STEP 8

Turn OFF the power to the robot controller.

**Caution:** The new software motion limit(s) specified for the motion space will take effect after the robot controller restarts and CAL is completed.

## 2.3 Changing the Mechanical End

This section describes the procedures of changing the mechanical ends from the 1<sup>st</sup>-axis to 3<sup>rd</sup>-axis.



### **CAUTIONS AT CHANGING THE MECHANICAL ENDS**

1. **When changing the mechanical ends, design the mechanical stoppers according to your usage and manufacture them.**
2. **After changing the mechanical end, the software motion limits (PLIMs, NLIMs) should be changed not to interfere the mechanical end at the robot operation.**
3. **The mechanical stoppers may not limit the workable area of the robot. Therefore, do not enter the robot's restricted space when the robot power is turned ON.**
4. **If the robot is collided with the mechanical stopper, the robot will stop by detecting the collision but the mechanical stopper may be broken.  
When the robot is collided with the mechanical stopper, remove the mechanical stopper. And inspect the robot and surrounding devices, and repair them. Do not re-use the mechanical stoppers and re-manufacture them.**
5. **The reference drawings described on this manual cannot be covered on the customer's usage conditions sufficiently. Design, manufacture and install the mechanical stoppers according to your usage conditions.**
6. **The weight addition by the mechanical stoppers may affect the maximum payload.**
7. **The failures caused by the mechanical stoppers shall not be covered by the warranty even if the robot is under warranty.**

## ■ The 1<sup>st</sup>-axis Mechanical End Change

### [ 1 ] What is the 1<sup>st</sup>-axis Mechanical End Change?


At the time of delivery from the plant, mechanical ends are set in the VS-E series so that the stroke of the 1st axis will be  $\pm 170$ .

Changing the mechanical ends of the 1st axis by adding mechanical stops is called a mechanical end change.

The figure below shows the positions of the mechanical stops at the time of mechanical end change.

The example when the mechanical stopper positions are as specified in the table below.

To change the mechanical ends, four types of mechanical stop parts are required—mechanical stop, fixture blocks A (2 pieces), fixture block B, and plates (2 pieces). Figures on the next pages show the reference drawings of those mechanical stop parts. Referring to those drawings, you should prepare mechanical stop parts as necessary so that your desired motion space may be set.




**Locations of Mechanical Stops in the VS-F Series**

If the 1st axis comes into contact with any mechanical stop because of the width of the stopper and its bolt, the angle of the 1st axis is different between the positive direction and the negative direction. The table below shows --- the angles of the 1st axis in the positive and negative directions when it is in contact with each mechanical stop.

**Stroke of the 1st Axis to Mechanical Ends**

Mechanical stop position	Positive direction	Negative direction
A'	5°	28°45'
A'	-28°45'	-5°
B'	95°	118°45'
B'	-118°45'	-95°
Permanent mechanical end	170°	-170°

VS-F series (For 1<sup>st</sup>-axis)




Material: S45C

(Note 1) Unless otherwise specified, corners should be C0.1 to C0.5.

**Mechanical Stop**

VS-F series (For 1<sup>st</sup>-axis)




Material: S45C

(Note 1) Unless otherwise specified, corners should be C0.1 to C0.5.

**Fixture Block A**

VS-F series (For 1<sup>st</sup>-axis)




Material: S45C

(Note 1) Unless otherwise specified, corners should be C0.1 to C0.5.

**Fixture Block B**

VS-F series (For 1<sup>st</sup>-axis)



Material: S45C

(Note 1) Unless otherwise specified, corners should be C0.1 to C0.5.

**4-13 Plate**

## Precautions When Changing the Mechanical Ends

After a mechanical end change, the software motion limits (PLIMs, NLIMs) must be changed.

And also, if you change the RANG values after a mechanical end change, the CALSET must also be performed.

### **Note:**

A RANG is the angle that determines the relationship between the reference position of the robot and the mechanical ends, and is also called a reference angle or ready angle.

(1) If the following case, the RANG values change and the CALSET are not necessary after a mechanical end change.

**If you can perform the CALSET after removing the mechanical stop parts prepared by you from the robot when the CALSET becomes necessary (Example: Exchanging the motor).**

(2) If the following case, the RANG values change and the CALSET are necessary after a mechanical end change.

**If you perform the CALSET for the robot with the mechanical stop parts prepared by you when the CALSET becomes necessary (Example: Exchanging the motor).**

In this case, the position repeatability is depended on the mechanical stop parts prepared by you.

And also you need to note down the new RANG values and CALSET values.

The initial RANG values and CALSET values at the time of delivery from the plant are saved in the initialization floppy disk.

In this example, after a mechanical end change, the RANG values must be changed, and CALSET must also be performed.


## [ 2 ] Changing the Mechanical Ends

The mechanical ends can be changed by mounting four types of mechanical stop parts (i.e., mechanical stop, fixture blocks A, fixture blocks B, and plates) and then changing the set software motion limits and the RANG values. The procedures for doing this are described in the following sections.

### (1) Mounting mechanical stop parts


#### ▶ STEP 1

Move the 1st axis of the robot until the stopper bolt comes into the inside of the motion space that you want to set.



## ▶ STEP 2

Secure fixture block A to the plate with two hexagonal socket-head bolts. (Make a pair of assemblies.)




VM-D series: Hex. socket-head bolt M10x25 (Strength class: 12.9)  
Tightening torque:  $71 \pm 14.2$  Nm

VS-E/F series: Hex. socket-head bolt M8x16 (Strength class: 12.9)  
Tightening torque:  $36 \pm 7.2$  Nm

## ▶ STEP 3

Turn each of the assemblies made in Step 2 upside down. Secure two mechanical stops to it with two hexagonal socket-head bolts each for determining the desired motion space.




VM-D series: Hex. socket-head bolt M10x25 (Strength class: 12.9)  
Tightening torque:  $71 \pm 14.2$  Nm

VS-E/F series: Hex. socket-head bolt M8x16 (Strength class: 12.9)  
Tightening torque:  $36 \pm 7.2$  Nm


## ▶ STEP 4

Temporarily secure one of the assemblies made in Step 3 to the side of the 1st axis with hexagonal socket-head bolts.




## ▶ STEP 5

In the same way as in Step 4, temporarily secure the other assembly made in Step 4 to the other side of the 1st axis.



## ► STEP 6

Link the assemblies together that you have temporarily secured in Steps 4 and 5, using fixture block B and hexagonal socket-head bolts. Then firmly tighten the hexagonal socket-head bolts tightened temporarily in Steps 4 and 5.



VM-D series: Hex. socket-head bolt M12x50 (Strength class: 12.9)  
Tightening torque:  $110 \pm 22$  Nm  
Hex. socket-head bolt M10x25 (Strength class: 12.9)  
Tightening torque:  $71 \pm 14.2$  Nm  
VS-E/F series: Hex. socket-head bolt M8x16 (Strength class: 12.9)  
Tightening torque:  $36 \pm 7.2$  Nm

## (2) Software motion limits and Set RANG values

**Note:** If the following case, the RANG values change and the CALSET are necessary after a mechanical end change.

**If you perform the CALSET for the robot with the mechanical stop parts prepared by you when the CALSET becomes necessary (Example: Exchanging the motor).**

In this case, the position repeatability is depended on the mechanical stop parts prepared by you.

And also you need to note down the new RANG values and CALSET values.

The initial RANG values and CALSET values at the time of delivery from the plant are saved in the initialization floppy disk.

The set software motion limits and RANG values must be changed whenever the mechanical end positions are changed. A RANG is the angle that determines the relationship between the reference position of the robot and the mechanical ends, and is also called a reference angle or ready angle. The RANG value checking procedure is given below.

The relationship between each mechanical end position and software motion limits is shown in the table on the next page.

Change the set software motion limits (PLIMs) and RANG values according to the procedures given in "(3) Changing positive-direction software motion limits (PLIMs) and RANG values" and "(4) Changing the negative-direction software motion limits (NLIMs)".

### Checking the set RANG values

After mounting the mechanical stop parts, check the RANG values according to the procedure below.


The RANG values that you check here should be entered in the procedure of "(3) Changing positive-direction software motion limits (PLIMs) and RANG values" and "(4) Changing the negative-direction software motion limits (NLIMs)."

When you use the permanent mechanical end, this checking job is not required.

- ▶ **STEP 1** | Turn the power switch of the robot controller to **ON**.
- ▶ **STEP 2** | Set the mode selector switch of the teach pendant to **MANUAL**.

### ▶ STEP 3

Press [F2 Arm] on the top screen.  
The Current Robot Position window appears.




### ▶ STEP 4

Gently bring the 1st axis of the robot into contact with the newly set positive-direction mechanical end.

### ▶ STEP 5

Check the value in J1 box that appears when the 1st axis is in contact with the mechanical end in Step 4. The value is RANG value to be newly set.



### Mechanical End Positions and Set Software Motion Limits

	Positive-direction mechanical end				Negative-direction mechanical end			
	A	B	A'	B'	A	B	A'	B'
Positive-direction software motion limit	0	90	-33.75	-123.75	/	/	/	/
Negative-direction software motion limit	/	/	/	/	33.75	123.75	0	-90

**Caution: If you set mechanical ends (in addition to the permanent mechanical end), set the software motion limits 5° inside from the mechanical ends (RANG value). If the software motion limits are set merely less than 5° inside from the mechanical ends, the robot may bump against the mechanical stops before it stops by software.**

- Examples
- (1) When the positive-direction mechanical ends are A and the negative-direction ones are the permanent mechanical ends, change:  
 Positive-direction software motion limit = 0  
 RANG = value obtained in "Checking the set RANG value"
  - (2) When the positive-direction mechanical ends are the permanent mechanical ends and the negative-direction mechanical ones are B', change:  
 Positive-direction software motion limit = -90
  - (3) When the positive-direction mechanical ends are B and the negative-direction mechanical ends are A', change:  
 Positive-direction software motion limit = 90  
 RANG = value obtained in "Checking the set RANG value"  
 Negative-direction software motion limit = 0
  - (4) When the positive-direction mechanical ends are A' and the negative-direction mechanical ends are the permanent mechanical ends, change:  
 Positive-direction software motion limit = -33.75  
 RANG = value obtained in "Checking the set RANG value"
  - (5) When the positive-direction mechanical ends are the permanent mechanical ends and the negative-direction mechanical ends are B, change:  
 Positive-direction software motion limit = 123.75

### (3) Changing positive-direction software motion limits (PLIMs) and RANG values

The set positive-direction software motion limits (PLIMs) and RANG values must be changed whenever the positive-direction mechanical ends are changed.

**Note:** If the following case, the RANG values change and the CALSET are necessary after a mechanical end change.

**If you perform the CALSET for the robot with the mechanical stop parts prepared by you when the CALSET becomes necessary (Example: Exchanging the motor).**

In this case, the position repeatability is depended on the mechanical stop parts prepared by you.

And also you need to note down the new RANG values and CALSET values. The initial RANG values and CALSET values at the time of delivery from the plant are saved in the initialization floppy disk.

Change the set positive-direction software motion limits (PLIMs) and RANG values according to steps 1 through 24 described below.

#### Changing Positive-Direction Software Motion Limits (PLIMs)

##### ▶ STEP 1

Turn the power switch of the robot controller to ON.

##### ▶ STEP 2


Set the mode selector switch of the teach pendant to MANUAL.

##### ▶ STEP 3

Press [F2 Arm] on the top screen.  
The Current Robot Position window appears.

##### ▶ STEP 4

Press [F12 Aux.].  
The Maintenance Functions (Arm) window appears.




F1

## ▶ STEP 5

**Press [F1 M Space.].**

The Motion Space (Software motion limit) window appears as shown below.



## ▶ STEP 6

Using the jog dial or cursor keys, select the Software motion limit (+J1, deg) field.

## ▶ STEP 7

**Press [F5 Change.].**

The numeric keypad appears.

## ▶ STEP 8

Using the numeric keys, enter the positive-direction software motion limit value, then press OK.

The screen returns to the Motion Space (Software motion limit) window.

## ▶ STEP 9

**Press OK.**


The screen returns to the Maintenance Functions (Arm) window.

## Changing Set RANG Values

### ► STEP 10

Press **[F2 RANG.]**.

The RANG window appears as shown below.




F5

### ► STEP 11

Press **[F5 Change.]**.

The numeric keypad appears.



### ► STEP 12

Using the numeric keys, enter RANG values, then press **OK**.

The screen returns to the RANG window.

▶ **STEP 13** | **Press OK.**  
The screen returns to the Maintenance Functions (Arm) window.

▶ **STEP 14** | **Turn the power switch of the robot controller to OFF.**


▶ **STEP 15** | **Turn the power switch of the robot controller to ON.**

▶ **STEP 16** | **Press [F2 Arm] on the top screen.**

### CALSET of the 1st Axis

▶ **STEP 17** | **Press SHIFT.**

▶ **STEP 18** | **Press [F12 Maint.]**  
The Maintenance Functions (Arm) window appears.




F6

▶ **STEP 19** | Bring the 1st axis into contact with the positive-direction mechanical end by hand.

## ▶ STEP 20

Press [F6 CALSET.] on the window in Step 18.  
The Set CALSET window appears.




## ▶ STEP 21

Touch the J1 field and confirm that the mark turns green.

## ▶ STEP 22

Press OK.  
The message window appears asking you whether you want to execute CALSET.



## ▶ STEP 23

**Press OK.**

The message window appears informing you that CALSET is completed.

## ▶ STEP 24

**Press OK.**

**Caution:** After CALSET is completed, move the 1st axis over the full stroke in the manual mode (speed = 10% or less) to confirm that the positive-direction and negative-direction software motion limits function properly. If they are valid, the axis stops just before the mechanical end, and ERROR6071 appears.

In the following cases, reset the bolt positions, the positive-direction software motion limits, the RANG values and the negative-direction software motion limits to the original settings, and repeat the procedure from the beginning:

- 1) The software motion limits do not function when the axis is near a mechanical end, and another error (6111, 6121 or 6171) occurs.
- 2) A software motion limit error (ERROR6071) occurs although the axis is not near a mechanical end.

#### (4) Changing set negative-direction software motion limits (NLIMs)

The set negative-direction software motion limits (NLIMs) must be changed whenever the negative-direction mechanical ends are changed. Change the set negative-direction software motion limits (PLIMs) according to steps 1 through 10 described below.

##### ▶ STEP 1


Turn the power switch of the robot controller to ON.

##### ▶ STEP 2

Set the mode selector switch of the teach pendant to MANUAL.

##### ▶ STEP 3


Press [F2 Arm] on the top screen.  
The Current Robot Position window appears.



F12

##### ▶ STEP 4

Press [F12 Maint.].  
The Maintenance Functions (Arm) window appears.




F1

## ▶ STEP 5

**Press [F1 M Space.].**

The Motion Space (Software motion limit) window appears.



## ▶ STEP 6

**Using the jog dial or cursor keys, select the Software motion limit (-J1, deg) field.**

## ▶ STEP 7

**Press [F5 Change.].**

The numeric keypad appears.

## ▶ STEP 8

**Using the numeric keys, enter a negative-direction software motion limit value, then press OK.**

The screen returns to the Motion Space (Software motion limit) window.

## ▶ STEP 9

**Press OK.**

## ► STEP 10

Turn the power switch of the robot controller to OFF.

**Caution:** After changing the software motion limit(s), move the 1st axis over the full stroke in the manual mode (speed = 10% or less) to confirm that the positive- and negative-direction software motion limits function properly. If they are valid, the axis stops just before the mechanical end, and ERROR6071 appears.

In the following cases, reset the bolt positions, the positive-direction software motion limits, the RANG values and the negative-direction software motion limits to the original settings, and repeat the procedure from the beginning:

- 1) The software motion limits do not function when the axis is near a mechanical end, and another error (6111, 6121 or 6171) occurs.
- 2) A software motion limit error (ERROR6071) occurs although the axis is not near a mechanical end.

## ■ The 2<sup>nd</sup>-axis and 3<sup>rd</sup>-axis Mechanical Ends Change

### [1] What is the 2<sup>nd</sup>-axis and 3<sup>rd</sup>-axis Mechanical Ends Change?

At the time of delivery from the factory, mechanical ends are set inside the VS-E series so that the workable angle of the 2<sup>nd</sup>-axis and 3<sup>rd</sup>-axis will be shown the table below (factory default).

**Note:** The limit to the workable angle of the robot is defined by the software motion limit. The software motion limit is set inside the mechanical end positions.

The workable angle at shipping for VS-F series

Model	Workable angle for the 2 <sup>nd</sup> -axis	Workable angle for the 3 <sup>rd</sup> -axis
VS-6356F series	+135°, -100°	+166°, -119°
VS-6377F series	↑	+169°, -119°

Changing the mechanical ends of the 2<sup>nd</sup>-axis and 3<sup>rd</sup>-axis by adding mechanical stoppers is called a mechanical end change.


To change the mechanical ends of the 2<sup>nd</sup>-axis and 3<sup>rd</sup>-axis, the mechanical stoppers should be prepared by the customer.

**Caution:** If changing the mechanical ends, the software motion limits should be changed to the positions inside the mechanical end positions.

## [2] Samples of mechanical stoppers

### [2.1] Sample of the mechanical stopper for 2<sup>nd</sup>-axis


The figure below shows the sample of the mechanical stopper for the 2<sup>nd</sup>-axis.





## [2.2] Example of installing the 3<sup>rd</sup>-axis mechanical end

The figure below shows the example of installing the 3<sup>rd</sup>-axis mechanical end and the fixing position.



Original thread holes for the 3<sup>rd</sup>-axis stopper



The 3<sup>rd</sup>-axis mechanical stopper for VS-6356F series




The 3<sup>rd</sup>-axis mechanical stopper for VS-6377F series



### [2.3] Reference drawings of the 2<sup>nd</sup>-axis and 3<sup>rd</sup>-axis mechanical stoppers for VS-6356F series


The sample mechanical stoppers are shown as follows to set the positive- and negative -direction limits to +67.5° and -50°, respectively for the 2<sup>nd</sup>-axis, and to set the positive - and negative - direction limits to +128° and -14.5°, respectively for the 3<sup>rd</sup>-axis.

#### (1) Example of installing the 2<sup>nd</sup>-axis and 3<sup>rd</sup>-axis mechanical stoppers for VS-6356F series




(2) Reference drawing for 2<sup>nd</sup>-axis mechanical stopper (VS-6356F series)

Reference drawing for 2<sup>nd</sup>-axis mechanical stopper (VS-6356F & VS-6377F series)



Material: A2017-T4

(3) Reference drawings for components of 3<sup>rd</sup>-axis mechanical stopper (VS-6356F series)






## [2.4] Reference drawings of the 2<sup>nd</sup>-axis and 3<sup>rd</sup>-axis mechanical stoppers for VS-6377F series


The sample mechanical stoppers are shown as follows to set the positive - and negative - direction limits to  $+67.5^\circ$  and  $-50^\circ$ , respectively for the 2<sup>nd</sup>-axis, and to set the positive - and negative - direction limits to  $+128^\circ$  and  $-14.5^\circ$ , respectively for the 3<sup>rd</sup>-axis.

### (1) Example of installing the 2<sup>nd</sup>-axis and 3<sup>rd</sup>-axis mechanical stoppers for VS-6377F series



(2) Reference drawing for 2<sup>nd</sup>-axis mechanical stopper (VS-6377F series)


Reference drawing for 2<sup>nd</sup>-axis mechanical stopper (VS-6356F & VS-6377F series)



Material: A2017-T4




Reference Drawing of the Stay for VS-6377F Series



Material: A2017-T4

Reference Drawing of the Spacer for VS-6377F Series



Material: S45C

## 2.4 CALSET

### 2.4.1 What Is CALSET?

Calibrating the relationship between position-related information recognized by the robot controller and the actual position of the robot unit is called CALSET.

CALSET must be performed when the motor is replaced or when the encoder backup battery goes dead and the position-related data retained in the encoder is lost as a result.

After CALSET is completed, the calibrated data of the robot unit will be stored in the robot controller. This data is called CALSET data which is different on each robot.


This robot has been CALSET before delivery and the CALSET data is stored in the floppy disks that come with the robot unit. Therefore, even if the memory backup battery in the robot controller dies so that the CALSET data is lost, you do not need to CALSET the robot. Just reload the CALSET data from the floppy disks.

### 2.4.2 Precautions about CALSET for the VS-F Series

(For models having no mechanical stop on the 4th-axis)

Robots in the VS-F series have **no mechanical stop on the 4th-axis**.


**If the 4th-axis CALSET position is wrongly set by one rotation (360°) while CALSET is being carried out, the internal wiring may be caught in the crank and broken.** To carry out CALSET with a robot with no 4th-axis mechanical stop, check the normal 4th-axis position first as described below.



**Note that turning the 4th-axis section by more than 360° may break the internal wiring**


## Checking of 4th-axis Position before Carrying Out CALSET

- (1) Manually move the 4th-axis section until the hand control signal connector comes to the upper side.
- (2) Dismount the cover from the second arm so that the internal wiring can be checked.  
The cover to dismount for each model is shown below:




- (3) Check that the 4th-axis section is at a designated position.  
(The hand control signal connector (CN21) of the second arm comes to the upper side and the internal wiring is not caught in the crank at this time.)

### ■ Checking of 4th-axis position for VS-6377F



■ Checking of 4th-axis position for VS-6356F



- (4) When the 4th-axis section is not at the normal position, manually move it to a designated position.

Preparation before carrying out CALSET is finished now.

**NOTE:** If the step [2.4.2] is omitted, the 4th-axis CALSET position may be mistaken by one rotation (360°). The internal wiring may be caught in the crank and broken in such a case.

### 2.4.3 Preparation for CALSET

In all models, the 1st, 2nd, 3rd, and 5th axes are equipped with mechanical stops but the 6th axis is not.

As for the 4th axis, the VS-F series have no mechanical stop on the 4th axis.

To CALSET those axes having no mechanical stop, you need to mount a CALSET jig before starting CALSET as described on the following pages.

**Mechanical Stops on Axes**

Model	On the 1st, 2nd, 3rd, 5th axes	On the 4th axis	On the 6th axis
VS-D series	Mechanical stops provided	Mechanical stops provided	No mechanical stops
VS-E/-F series		No mechanical stops	

### **(1) If your model has a mechanical stop on the 4th axis (VS-D series)**

Press each of the 1st to 5th axes manually against the associated mechanical stop and get the actual position.

Since the 6th axis has no mechanical stop, you need to mount a CALSET jig to set a temporary mechanical end for CALSET. Then press the 6th axis against this mechanical end and get the position. When CALSETing the 6th axis, you need to press also the 5th axis against the mechanical stop since CALSET requires the positional relationship between the 5th and 6th axes.

### **(2) If your model has no mechanical stop on the 4th axis (VS-E/-F series)**

Press each of the 1st, 2nd, 3rd, and 5th axes manually against the associated mechanical stop and get the actual position.

Since the 4th and 6th axes have no mechanical stop, you need to mount a CALSET jig to set a temporary mechanical end for CALSET. Then press the 4th and 6th axes against those mechanical ends and get the those positions. When CALSETing the 6th axis, you need to press also the 5th axis against the mechanical stop since CALSETing requires the positional relationship between the 5th and 6th axes.

### **(3) Cautions at CALSET**

CALSET requires some space for bringing each axis into contact with the mechanical end.

- Caution (1) When CALSETing, move the axis to be CALSET in the vicinity of the mechanical stop, release the brake, and bring the axis into contact with the mechanical stop.**
- The VM-D/VS-E/-F series may release the brake of the specified axis, but the VS-D series will release brakes of all axes.
  - VM-D series and the brake-equipped version of the VS-D/-E/-F series: Each of the 2nd through 6th axes has a brake.
  - None-brake version of the VS-D series: Only the 2nd and 3rd axes have brakes.
  - None-brake version of the VS-E/-F series: Only the 2nd to 4th axes have brakes.
- (2) When performing CALSET, be careful with the robot motion. The execution of the CALSET command releases motor brakes so that the robot arms will move by its own weight.**
- (3) After CALSET, confirm in the manual mode that each axis stops at the software motion limit before coming into contact with the mechanical end.**
- (4) In automatic operation, start to run the robot at low speed. Ensuring safety, gradually increase the speed. It makes adjustment easy.**
- (5) Position-related data in some programs made before CALSET may vary somewhat after CALSET.**
- (6) For models having no mechanical stop on the 4th axis:**
- When rotating the 4th axis with the brake released, take care not to let the 4th axis override the motion limit (initial setting of the software motion limit). Rotating it beyond the motion limit will cause the brake (even released) to be locked, turning the motor off.**
- Be careful with arms that may rotate by gravity after brakes are released depending upon the robot posture and hand position.**

## 2.4.4 Mounting the CALSET Jig


To CALSET the 6th axis on all models or the 4th axis on models having no mechanical stop, you need to mount the CALSET jig on the axis beforehand according to the procedure given in (1) below or (2) given later, respectively.

To CALSET all axes including the above axes, follow those procedures (1) and (2).

### (1) Mounting the CALSET jig on the 6th axis

#### ► STEP 1

Fit a stopper pin in the CALSET jig.




#### ► STEP 2

Release the brake of the 6th axis.

### ▶ STEP 3

Install the CALSET jig on the 6th axis flange as shown in the figure below.

**TIP:** The CALSET position of the 6th axis refers to the point where the stopper pin (shown in the figure below) comes into contact with bolt (A) by turning the flange of the 6th axis.



**Mounting a CALSET Jig (VS-F series)**


## (2) Mounting the CALSET jig on the 4th axis

As a CALSET jig, a special bolt (CALSET bolt) is provided inside the 3rd-axis motor cover in the robot unit.

### ▶ STEP 1

Remove the 3rd-axis motor cover and unscrew the CALSET bolt.

**NOTE: After CALSETing, be sure to set the bolt back into place and torque it to 1.0 Nm  $\pm$ 20%.**



**Removing the CALSET Bolt (VS-F series)**

### ▶ STEP 2

Rotate the second arm to the position specified in the STEP 4.

### ▶ STEP 3

Release the brake of the 4th axis.


## ► STEP 4

Set the CALSET bolt to the end of the 3rd axis housing as shown in the figure below.

Tightening torque of the CALSET bolt:  $2.9 \text{ Nm} \pm 20\%$

**NOTE:** Be sure to use the CALSET bolt as a CALSET jig. Using any other bolt will result in a positional error in CALSET.

**TIP:** The CALSET position of the 4th axis refers to the point where the notch of the second arm comes into contact with the head of the CALSET bolt by turning the second arm.




**Mounting the CALSET Bolt (VS-F series)**

## 2.4.5 What Is a CALSET Position?

The limit position of an arm to be CALSET is called a CALSET position.

Each axis has a mechanical end in each of the positive and negative directions. The mechanical ends shown in the figure below are the CALSET positions.

Axis		CALSET position
Position	1st axis	Turning end in the positive direction (counterclockwise end when viewed from top)
	2nd axis	Turning end in the negative direction
	3rd axis	Turning end in the positive direction
	4th axis	Turning end in the positive direction, which is set by a CALSET jig. (See Section 2.4.4.) (counterclockwise end when viewed from the arm end)
	5th axis	Turning end in the positive direction (upward end of the 5th-axis arm)
	6th axis	Turning end in the positive direction, which is set by a CALSET jig. (See Section 2.4.4.)



**CALSET Positions (VS-F series)**

## 2.4.6 CALSET Procedure

### 2.4.6.1 CALSETing a Single Axis

CALSETing a specified single axis only is called single-axis CALSET.

Perform single-axis CALSET if the motor of an axis is replaced so that the axis must be CALSET, or if some axes cannot be moved to the CALSET positions (mechanical stop positions) at any given time because of interference between the robot unit and its surrounding facilities.

**NOTE:** Step 1 is required for CALSETing the 4th and 6th axes and Step 2 is for CALSETing the 6th axis. When CALSETing any other axes, skip to Step 3.

#### ▶ STEP 1


(Required for CALSETing the 4th and 6th axes)

Mount the CALSET jig according to Subsection 2.4.2.1 "Mounting the CALSET Jig."

#### ▶ STEP 2

(Required for CALSETing the 6th axis)

Fully turn the 5th axis to its turning end in the positive direction.



Turn the 5th axis to its turning end

#### ▶ STEP 3

Turn the power switch of the robot controller to ON.

#### ▶ STEP 4

Set the mode selector switch of the teach pendant to MANUAL.

#### ▶ STEP 5

Press MOTOR to turn ON the power to the motor.

#### ▶ STEP 6

Move the axis to be CALSET in the vicinity of the mechanical stop via the manual operation from the teach pendant.

▶ **STEP 7**


Press the MOTOR key on the teach pendant to turn OFF the power to the motor.

▶ **STEP 8**

Press [F2 Arm] on the teach pendant.

▶ **STEP 9**


Press the SHIFT key and [F12 Maint.].



F12

▶ **STEP 10**

Press [F3 Brake.].




F3

## ▶ STEP 11

### ■ VS-E/-F/VM-D Series

Touch the axis number to be CALSET to select "Brake released" (green display).



## ▶ STEP 12


Confirm that there is no danger even if the arms fall as a result of released brakes.

**CAUTION:** In the VS-E/-F series and VM-D series, the brake of the specified axis is released.

## ▶ STEP 13

Press OK.

The system message appears asking you whether you want to change the brake settings.




## ▶ STEP 14

### ■ VS-E/-F/VM-D Series

Press OK.

The system message appears informing that the brake is released and warning against drop of arms.




## ▶ STEP 15

Press the axis to be CALSET against the mechanical stop by hand.

## ▶ STEP 16


Press [F6 CALSET].

The Set CALSET window appears.



## ▶ STEP 17

Press the axis number to be CALSET to select CALSET (green display). Deselect CALSET (black display) for the other axes that are not required to be CALSET.



## ▶ STEP 18

Press OK.

The system message appears asking whether you want to carry out CALSET and showing a caution that the robot reference position will change.



## ▶ STEP 19

Press OK.

The system message appears informing that CALSET is completed.

## ▶ STEP 20

Press the ROBOT STOP button.  
The robot brake becomes activated.

## ▶ STEP 21

Turn the ROBOT STOP button to cancel robot stop.

## ▶ STEP 22

Press the MOTOR to turn ON the power to the motor.

**Caution: A "motor lock overload" error may occur just after the power to the motor is turned ON. In this case, try to turn ON the power several times, or release the brake, move the axis a little in the opposite direction of the mechanical end, and turn ON the power again.**

## ▶ STEP 23

Move the CALSETed axis in the opposite direction from the mechanical end by the manual operation of the teach pendant.

## ▶ STEP 24

Perform CAL. The single-axis CALSET of the specified axis is completed.

### 2.4.6.2 CALSETing All Axes

The CALSET of all axes is called all-axis CALSET.

The procedure is the same as that for single-axis CALSET except that you should select all axes for brake release and CALSET in Steps 9, 13 and 15. For details of the procedure, see Subsection 2.4.6.1 "CALSETing a Single Axis."

## 2.5 Setting Control Set of Motion Optimization


The optimum speed or acceleration will vary depending upon the payload and center of gravity of an end-effector or workpiece that is to be set at the end of the robot flange. Set the payload and center of gravity position of the end-effector or workpiece and the control set of motion optimization according to the payload and robot posture.

The mass of payload is a total mass of an end-effector and workpiece, expressed in grams.


For further information, see the PROGRAMMER'S MANUAL, Section 4.7 "Setting the Master Control Parameters in User Preferences." For the setting procedure, refer to the SETTING-UP MANUAL, Section 2.9, "Setting the Master Control Parameters of the Payload, Center of Gravity, and Control Set of Motion Optimization."

The payload center of gravity is represented by the TOOL0 coordinate system (see the figure below) in the unit of mm.

The origin of the TOOL0 coordinate system is the center of the 6th axis flange. Its Y-component is in the direction from the flange center to the  $\phi 6H7$  pin hole (orientation vector direction). The Z-component is in the vertical direction to the flange face across the flange center (approach vector direction). The X-component is in the X-axis direction of the right hand coordinate system (normal vector direction) with the orientation vector as the Y-axis and the approach vector as the Z-axis. (See the figure on the next page.)



**Payload Center of Gravity**



**Right Hand Coordinate System**

## **2.6 Setting Robot Installation Conditions**

The optimum operating conditions will differ depending on whether the robot is floor-mounted or overhead-mounted.

When the robot leaves the factory, it is set for floor-mount. If you overhead-mount your robot, you need to change the installation settings.

For the setting procedure, refer to the SETTING-UP MANUAL, Section 2.10, "Setting the Robot Installation Condition" and the PROGRAMMER'S MANUAL, Subsection 4.7.3 "Setting Robot Installation Conditions."

# Chapter 3 Maintenance and Inspection

## 3.1 Maintenance & Inspection Intervals and Purposes

Carry out the maintenance and inspection jobs show in the table below.

**⚠ Caution: Before performing maintenance and inspection jobs, read the SAFETY PRECAUTIONS, "3 Precautions while robot is running" and "4 Daily and periodical inspections."**

### Maintenance & Inspection Intervals and Purposes

#### ■ VS-F series

No.	Intervals		Purposes
1	Daily	Perform inspection jobs specified in <u>Section 3.2</u> every day before starting operations.	To use your robot safely.
2	Quarterly	Perform inspection jobs specified in <u>Section 3.3</u> every three months.	To maintain the precision of the robot and to prevent failures caused by overheat of the robot controller.
3	Biennial	Replace backup batteries as specified in <u>Section 3.4</u> every two years.	To retain the robot-specific data (programs, parameters, etc.) stored in the internal memory of the robot controller and the position data stored in the electronic absolute encoder build in the robot unit.  To check the rotary sections and slideways of the robot for wear, preventing seizure, breakage, and other serious failures that could result from wear.

## 3.2 Daily Inspections

### 3.2.1 Check Items


Before starting operation every day, check the items listed in the table below.

**Daily Inspections Table**

No.	Check:	Controller Power	How to check:	Criterion	What to do: (Note 1)
1	Connectors (CN1 to CN12 on the robot controller) and their mating parts	OFF	Visually	No looseness, disengagement or dirt.	Engage the parts properly and clean them.
2	Cables (connected to CN1 to CN12 on the robot controller) and robot's external cables	OFF	Visually	Free of damage or gouges.	Repair or replace.
3	LCD on the teach pendant	ON	Visually	Properly displayed	Repair or replace.
4	Pilot lamps on the robot controller	ON	Visually	Should light.	Repair or replace.
5	Cooling fan in the robot controller	ON	Visually <b>(Note 2)</b>	Should work properly.	Repair or replace.
6	Calibration	ON	Visually	No error or unusual noise.	Repair or replace.
7	ROBOT STOP button on the teach pendant or the mini pendant	ON	Press the ROBOT STOP button.	The robot should come to an emergency stop.	Repair or replace.
8	Safety door	ON	Operate the safety door switch and open the switch-wiring door.	The robot should come to an emergency stop.	Repair or replace.

Note 1 Some repair and replacement operations, shown in "What to do:" column, may involve special work. Contact our Robot Service Section.

Note 2 The normal operation of the cooling fan is as shown in the figure on the next page.



**Normal Operation of Cooling Fan (VS-F)**

### 3.3 Quarterly Inspections

#### 3.3.1 Check Items

Check the items listed in the table below every three months.

**Quarterly Inspections Table**

No.	Check:	Controller Power	How to check:	Criterion	What to do:
1	Robot base mounting bolts	OFF	Measure the tightening torque with a torque wrench.	No looseness. Specified torque: 110 ±22 Nm	Tighten the bolts to the specified torque.
2	Cooling fan filters in the robot controller	OFF	Visually	No dust or dirt.	Clean the cooling fan filters. (Refer to Subsect. 3.3.2.)

#### 3.3.2 Cleaning the Air Intake Filter in the Robot Controller

For the cleaning procedures of the air intake filter, refer to the “ Section 6.5 Cleaning the Air Intake Filter, RC7 CONTROLLER INTERFACE MANUAL”.

## 3.4 Biennial Inspections

### 3.4.1 Battery Replacement and Check Items

Replace the two types of backup batteries listed in the upper table on this page and inspect the timing belts for the 5th and 6th axes shown in the lower table on this page during biannual inspection and maintenance.

**Backup Battery Types**

	Battery type	Used to:	Located:	Refer to:
1	Encoder backup battery	Back up the position data of the servomotor encoder.	In the robot unit	Subsect. 3.4.2
2	Memory backup battery	Back up programs, parameters, and CAL data.	In the robot controller	Subsect. 3.4.3

The position data of the encoder built in the servomotor is stored in the internal memory of the encoder.

Programs, parameters, CAL data, etc. are stored in the internal memory of the robot controller.

The backup battery for each memory retains the above data while the power to the robot controller is turned OFF. However, these batteries have a limited lifetime and must, therefore, be replaced regularly.

**NOTE:** If two years elapse from replacement of either backup battery, the "Time to change controller backup battery" message will appear on the teach pendant.

**⚠ Caution: Without replacing the backup batteries, important robot-specific data stored in each memory will be lost.**

**Biennial Inspection Table (VS-F series)**


No.	Check:	Controller Power	How to check:	Criterion	What to do:
1	Timing belts on the 5th and 6th axes	OFF	Visually	No lack of teeth or excessive wear.	Contact our Robot Service Section.

### 3.4.2 Replacing the Encoder Backup Battery

Replace the encoder backup battery according to the procedure below.


#### ▶ STEP 1

Prepare a new set of 3 backup batteries for replacement.




#### ▶ STEP 2

Turn the controller power OFF.




#### ▶ STEP 3

Remove the cover from the robot unit.




Cross pan-head screw

Standard type



Hex. socket-head bolt


Dust-proof & splash-proof type



## ▶ STEP 4


**Remove the dummy connector cap from the battery board.**

Dummy connector cap



## ▶ STEP 5

**Connect a new battery (1st one) to the pin from which you have disconnected the dummy connector cap in Step 4.**




New backup battery


**Note: Do not disconnect old backup batteries before connecting a new one to the pin from which the dummy connector cap is removed. If you do so, the encoder positional data may be lost.**

## ▶ STEP 6

Disconnect the old backup battery that is right next to the new battery connected in Step 5, and then connect a new battery (2nd one).




Old backup battery




New backup battery

## ▶ STEP 7

Disconnect the old backup battery that is right next to the new battery connected in Step 6, and then connect a new battery (3rd one).



Old backup battery




New backup battery

**Note:** Be sure to replace all of three batteries with new ones at one time. Otherwise, the battery service life will become short.


## ▶ STEP 8

Remove the last old battery and connect the dummy connector cap disconnected in Step 4.



## ▶ STEP 9

Install the cover to the robot unit.



Tightening torque:

Cross pan-head screw: 0.59 Nm (Standard type)

Hex. socket-head bolt: 2.0 Nm (Dust-proof, splash-proof type)

### 3.4.3 Replacing the Memory Backup Battery

For the replacing procedures of the memory backup battery, refer to the “ Section 6.6 Replacing the Memory Backup battery, RC7 CONTROLLER INTERFACE MNUAL”.

### 3.4.4 Setting the Next Battery Replacement Date

After replacing the memory backup battery, set the next battery replacement date from the teach pendant, according to the following procedure.

**NOTE:** This procedure cannot be performed with the mini pendant.

**NOTE:** Check that the system clock of the robot controller shows the correct date beforehand. If it is incorrect, the next replacement date will also become incorrect.

- ▶ **STEP 1** | **On the top screen of the teach pendant, press [F6 Set].**  
The Settings (Main) window appears.
- ▶ **STEP 2** | **Press [F6 Maint.] in the Settings (Main) window.**  
The Maintenance menu appears.
- ▶ **STEP 3** | **Press [F4 Battery] in the Maintenance menu.**  
The Next Battery Replacement Date window appears.  
In the top of the window, the current setting is displayed.  
The date entry areas show the default replacement date that is two years later the current data at which you open this window, assuming that the battery service life is two years.
- ▶ **STEP 4** | **Press OK.**  
**NOTE:** If you do not want to change the replacement date, press Cancel.  
The message "Are you sure you want to set the next battery replacement date?" appears.
- ▶ **STEP 5** | **Press OK.**  
The screen returns to the Settings (Main) window.

## 3.5 Supplies and Tools for Maintenance

The table below shows the supplies out of components used in DENSO robots that require periodic replacement and the tools recommended for maintenance and inspection.

### 3.5.1 Supplies and Tools Required

**List of Supplies and Tools Required**

No	Name	Part No.	Remarks
1	Filter	410041-4730	Air intake filter in the robot controller
2	Memory backup battery	410076-0260	Memory backup battery for controller
3	Encoder backup battery	410611-0070	3-battery set
4	Fuse (1.3A)	410054-0230	Fuse LM13 (1.3A) for controller I/O
5	Fuse (0.3A)	410054-0240	Fuse LM03 (0.3A) for controller I/O
6	IC for output (NPN)	410077-0010	IC (M54522P) for controller output
7	IC for output (PNP)	410077-0020	IC (M54564P) for controller output
8	CALSET jig	410192-0010	For 6th-axis CALSET

### 3.5.2 Recommended Tools

**List of Recommended Tools**

No.	Tool name	Recommended tool (manufacturer)	Application
1	Grease gun	(Yamada Corporation) ·Body: KH-32 ·Standard nozzle: HSP-1	Greasing

## 3.6 Replacing Fuses and Output ICs

For the replacing procedures of the fuses and output ICs, refer to the “ Section 6.7 Replacing Fuses and Output ICs, RC7 CONTROLLER INTERFACE MNUAL”.

## 3.7 Checking the Odometer and Trip Meter

You may check the odometer and trip meter which count traversed distance of each axis in the Odometer window of the teach pendant. With the trip meter, you may learn when oil change should be made.

The access to the Odometer window is [F6 Set]—[F6 Maint.]—[F5 Odometer].

The Odometer window shows the following items:

---

[Odometer]	Shows the total distance of each axis traversed after the robot leaves the factory. You cannot reset the odometer.
[Trip meter]	Shows the distance of each axis traversed after you reset the trip meter to zero.
[Interval]	Shows the oil change intervals specified for each axis, as a guide.

---

### 3.7.1 Displaying the Odometer, Trip Meter, and Oil Change Intervals

#### ▶ STEP 1

Turn the controller power ON.


#### ▶ STEP 2

On the teach pendant, set the mode switch to the MANUAL position.

#### ▶ STEP 3

On the top screen, press [F6 Set].

The Settings (Main) window appears as shown below.




F6

Press [F6 Maint.].

## ► STEP 4

The Maintenance menu appears as shown below.




F5

Press [F5 Odometer].

## ► STEP 5

The Odometer window appears as shown below.



F6

In the above Odometer window, the J1 through J6 are expressed in rpm.


If the Trip meter count exceeds the Interval value, the oil change prompt message will appear.

### 3.7.2 Resetting the Trip Meter to Zero

#### ► STEP 1

On the top screen, press [F6 Set].

The Settings (Main) window appears as shown below.




F6

Press [F6 Maint.].

#### ► STEP 2

The Maintenance menu appears as shown below.




F5

Press [F5 Odometer].

### ► STEP 3

The Odometer window appears as shown below.




F6

Press [F6 Reset].

### ► STEP 4

The following message appears.



Press the OK button.

The trip meter has been reset to zero.

### 3.8 Checking the Controller ON-Time and the Robot Running Time and Resetting Their User Counters


You may check the robot controller ON-time and the robot running time in the Total hours window of the teach pendant.

The Total hours window shows the following items:

[Total operation]	Shows the grand total of the robot controller ON-time counted after the controller leaves the factory.
[Total running]	Shows the grand total of the robot running time counted after the robot leaves the factory.
[Cumulative operation]	Shows the total of the robot controller ON-time counted after you reset the user counter to zero.
[Cumulative running]	Shows the total of the robot running time counted after you reset the user counter to zero.
[Operation]	Shows the ON-time of the robot controller counted after it is turned ON this time.
[Running]	Shows the running time of the robot counted after the robot controller is turned ON this time.

#### 3.8.1 Displaying the Controller ON-time and the Robot Running Time

- ▶ **STEP 1** Turn the robot controller power ON.
- ▶ **STEP 2** On the teach pendant, set the mode switch to the MANUAL position.
- ▶ **STEP 3** On the top screen, press [F6 Set].  
The Settings (Main) window appears as shown below.




F6

Press [F6 Maint.].

## ► STEP 4

The Maintenance menu appears as shown below.




F1

Press [F1 Total h].

## ► STEP 5


The Total hours window appears as shown below.



### 3.8.2 Resetting the User Counters of the Controller ON-Time and the Robot Running Time

#### ▶ STEP 1

On the teach pendant, press [F6 Set].  
The Settings (Main) window appears as shown below.




F6

Press [F6 Maint.].

#### ▶ STEP 2

The Maintenance menu appears as shown below.




F1

Press [F1 Total h].

### ► STEP 3

The Total hours window appears as shown below.




F4

To reset the user counter of the controller ON-time to zero, press [F4 Cumu. o].


### ► STEP 4

The following system message appears.



Press the OK button.

The user counter of the controller ON-time has been reset to zero.



## 3.9 Resetting Encoders

You need to reset encoders and perform CALSET if:

- Error 641\* occurs due to run-down encoder backup batteries, or
- Error 677\* occurs due to a great impact applied to the robot when the power is off.

(\* is any of 1 to 6 denoting the object axis.)

This section describes how to reset encoders.

For the encoder resetting procedure, refer to the “SETTING-UP MANUAL, Section 5.3, [F2 Arm]-[F12 Maint.]-[M11 ENC rest]”.

### 3.10 Using the Initialization Floppy Disk

The initialization floppy disk (\*.arm) stores arm data in WINCAPSII format.

You transfer the stored arm data to the robot controller in these two steps:

- (1) Create a project by using the data stored in the floppy disk.
- (2) Transfer the trajectory generation file in the project to the robot controller.

#### Creating a project to be transferred

##### ▶ STEP 1

##### Create a new project.

Start WINCAPSII. From the File menu of System Manager, click the New Project.




[File menu: Creating a new project]

##### ▶ STEP 2

##### Select your robot type.

Select the robot type of the controller to which you want to transfer data.




[Create New Project window]

## ▶ STEP 3

### Select arm data.

- (1) Press the Details button to call up the window below.




Browse button

[Details window]

- (2) Press the Browse button in Arm Manager to call up the Open Project window.

Select desired file in the floppy disk, then press the Open button.



File "Vm-6083d.arm"  
in drive A is selected.

[Selecting a file]

- (3) The screen will return to the Details window where you press OK button.

## ▶ STEP 4

### Create a project.

On the Create New Project window, press OK button. Now, a project to be transferred has been created.

## Transferring the trajectory generation file

### ▶ STEP 1


#### Start of Arm Manager

From System Manager, run Arm Manager.

### ▶ STEP 2

#### Connection with the robot controller

Press the Connect button to connect with the robot controller.




[Arm Manager window]

## ▶ STEP 3


### Data transmission

- (1) From the File menu of Arm Manager window, click Transfer command. The Transfer Environment Table appears as shown below.




[Transfer Environment Table]

- (2) On the table shown above, select the Trajectory and press the Transmit> button.
- (3) The following message appears.  
Press Yes.




[Confirmation dialog]

The following message appears.  
Press OK.



[Configuration transfer dialog]

During data transfer, the following dialog is displayed.




[Transfer Trajectory Generation Table]

(4) Upon completion of transfer, the following message appears.

Press OK.

The arm data stored in the initialization floppy disk has been transferred to the robot controller.

Turn the controller power off and then on.



[Transfer completion message]

# Index

## A

Ambient Temperature ..... [2](#)

## B

Backup Battery Types ..... [71](#)

Battery Replacement..... [71](#)

Biennial..... [68](#)

Biennial Inspections..... [71](#)

## C

CALSET ..... [51](#)

CALSETing a Single Axis ..... [60](#)

CALSETing All Axes ..... [65](#)

center of gravity position of end-effector ..... [11](#)

Control Set of Motion Optimization ..... [66](#)

Controller ON-time..... [82](#)

Cooling Fan Filters ..... [70](#)

## D

Daily ..... [68](#)

Daily Inspections ..... [69](#)

## E

Encoder Backup Battery ..... [72](#)

End-effectors..... [11](#)

## F

Factory Defaults of Software Motion Limits ..... [16](#)

Fuses ..... [77](#)

## G

Grounding the Robot Unit ..... [10](#)

## H

Humidity..... [2](#)

## I

Initialization Floppy Disk ..... [88](#)

Installation Conditions ..... [67](#)

Installation Environments ..... [1](#)

Installing the Robot Unit ..... [5, 9](#)

## M

Maintenance & Inspection ..... [68](#)

Mass of end-effector ..... [11](#)

Memory Backup Battery..... [76](#)

Moment of inertia ..... [12](#)

Moment-of-Inertia Formulas..... [12](#)

## N

negative-direction software motion limits (NLIMs) .. [38](#)

Next Battery Replacement Date..... [76](#)

## O

odometer ..... [78](#)

Oil Change Intervals ..... [78](#)

ON-time ..... [82](#)

## P

positive-direction software motion limits (PLIMs).... [32](#)

## Q

Quarterly ..... [68](#)

Quarterly Inspections ..... [70](#)

## R

RANG ..... [29](#)

Resetting Encoders (VS-D Series)..... [87](#)

Resetting the Trip Meter to Zero..... [80](#)

Resetting the User Counters..... [84](#)

Robot Running Time ..... [82](#)

## S

Software motion limits..... [15, 29](#)

Supplies..... [77](#)

## T

Tools..... [77](#)

Transporting the Robot Unit ..... [6](#)

trip meter..... [78](#)

## U

user counters ..... [82](#)

## V

Vibration ..... [2](#)

## W

What Is Customization..... [14](#)



# **Vertical Articulated Robot VS-F SERIES**

---

## **INSTALLATION & MAINTENANCE GUIDE**

First Edition February 2004  
DENSO WAVE INCORPORATED  
Factory Automation Division

2F\*\*C

---

The purpose of this manual is to provide accurate information in the handling and operating of the robot. Please feel free to send your comments regarding any errors or omissions you may have found, or any suggestions you may have for generally improving the manual.

In no event will DENSO WAVE INCORPORATED be liable for any direct or indirect damages resulting from the application of the information in this manual.

