


Outline of Win32 NetwoRC.dll




How to use Win32 NetwoRC.dll


1. Check the NetwoRC.dll library location.

[Note] ORiN2 SDK 2.1.2 or later. (Not released yet)


2. Just copy the library file into the user application directory.
3. Call the functions from the application in the same way as the other win32 DLLs.




Sample Flow (1) Variable Read and Write



Sample Flow (2) Program Start and Stop



Sample Flow (3) Robot Motion



Sample Flow (4) Robot Calibration

