

OPTIONAL COMPONENTS LISTS (T03)

I/O cables

Standard I/O cable set	(8 m) Incl. Nos. 1-1 and 1-2.	410149-0940
I/O cable for "Mini I/O" (68 pins)	(8 m)	410141-2700
I/O cable for "HAND I/O" (20 pins)	(8 m)	410141-1740
Standard I/O cable set	(15 m) Incl. Nos. 1-1 and 1-2.	410149-0950
I/O cable for "Mini I/O" (68 pins)	(15 m)	410141-2710
I/O cable for "HAND I/O" (20 pins)	(15 m)	410141-1750
X-LNE1 cable (T03) (28 pins)	(8 m)	410141-4210
	(15 m)	410141-4220
S ON cable (T03) (15 pins)	(8 m)	410141-4260
	(15 m)	410141-4270
X-10A3 cable (T03) (50 pins)	(8 m)	410141-4240
	(15 m)	410141-4250
Line controller conversion cable (T03)	(1 m)	410141-4200

Operation devices

Teach pendant (T03)	(8 m) With cable	Japanese version	410100-1690
		English version	410100-1700
Operation panel (T03)	(3 m) With cable	Japanese version	410100-1670
		English version	410100-1680
Pendant extension cable (T03)	(4 m)		410141-4320
Dummy connector			410142-0400

Optional boards for the robot controller

Image processing board	Shipped as installed on the controller	410010-4150
	Shipped as individual boards (supply part)	410010-4160

Optional functions (For customerprocured extended boards etc.)

Optional function for memory extension	Extension only upon controller shipment (Only program area expandable from 3.25 MB to 5.5 MB)	410006-0320
Controller protection box		410181-0091

CD Manuals

Manual Pack CD (T03)	Contained in the robot package.	410002-3120
----------------------	---------------------------------	-------------

For robot unit

Flange kit (For HS)		410329-0060
Flange kit (For HM)	For 10 kg payload	410329-0070
Flange kit (For HM)	For 20 kg payload	410329-0080

Programming support tool

WINCAPS III (T03)	CD-ROM (common to the languages-- Japanese and English)	410090-0990
-------------------	---------------------------------------------------------	-------------