






<HS045A1-S\*-W5N>




工具安装面详图 (视图D)



法兰盘 (选件) 安装图



底座安装尺寸



单位: mm

注: Z轴行程(S)不同的各寸法

型式	S	L1	L2
HS045A1-S10-W5N	100	14	571
HS045A1-S15-W5N	150	64	621
HS045A1-S20-W5N	200	114	671
HS045A1-S32-W5N	320	234	791

注: 属于悬挂型时, Z轴的最上端将到达高于基准安装面的位置, 因此请注意与周边装置的干涉。